NOTES:

- REFER TO THE PLANS AND LEGEND FOR SIZES OF LATERAL LINES & FLEX HOSE, EMITTER MODELS & FLOW RATES, AND NUMBER OF EMITTERS PER PLANT.
- ON SLOPES, INSTALL THE UVR-PVC DISTRIBUTION LINES PARALLEL TO THE SLOPE AS SHOWN ON THE PLANS.
- 3. ON SLOPES, INSTALL EMITTERS ON UPHILL SIDE OF PLANTS.

